


BIOS or UEFI SETUP UTILITY required settings for the Motherboard



To Enter the BIOS screen (UEFI SETUP UTILITY):

Turn on the computer and when the ASRock Logo screen appears, press the DELETE key several times in succession.



The screen on the left should then appear

Using the Cursor Keys go across to the OC Tweaker Menu and then down to DRAM Configuration and press Enter.

Select PROFILE 1 and press Enter.

This ensures the correct settings are used for the RAM on the system.

Press ESC to go back to the MAIN MENU



From the MAIN MENU go across to ADVANCED MENU and then down to STORAGE CONFIGURATION and press Enter

BIOS or UEFI SETUP UTILITY required settings for the Motherboard (cont)



Change all IDE modes to AHCI


If you have a RAID configuration then change this setting to RAID

Press ESC to back to the MAIN MENU

This where you can select which hard drive the system boots up on first (or DVD drive)

You can also select the order of the hard drives here. If you are "missing" a hard drive check here.

Press ESC to back to the MAIN MENU



Press F10 to SAVE CHANGES and EXIT

Or from the MAIN MENU go to EXIT MENU and select SAVE CHANGES & EXIT and press ENTER.

The system will reboot.

