


# Reseating an INTEL FAN & HEATSINK



The picture on the left shows an Intel Fan & Heatsink in its normal locked down position. Note the position of the 4 x Black TABS and the way they face.



Take a screwdriver and turn each Black TAB 1/4 turn anti-clockwise as in the picture on the right.



Each Black Tab should now lift up releasing the Fan & Heatsink away from the motherboard.

Turn each Black Tab back 1/4 turn **CLOCKWISE** before returning it to the motherboard.

Align the heatsink to the holes on the motherboard and follow the picture below.



Make certain the plastic pins on the underside are not bent and fit through the holes on the motherboard.

