

Changing the BIOS back to RE-INSTALL your Operating System

Enter BIOS Setup

The BIOS is the communication bridge between hardware and software. Correctly setting the BIOS parameters is critical to maintain optimal system performance.


Use the following procedure to verify/change BIOS settings.

1. Power on the computer,
2. Press the **Del** key when the following message briefly displays at the bottom of the screen during the Power On Self Test (POST).


Press F1 to continue, DEL to enter Setup.

Pressing **Del** takes you to the Phoenix-Award BIOS CMOS Setup Utility.


Enter the BIOS utility using the above Instructions.
The below screen should appear



Scroll down (use cursor keys) to ADVANCED CHIPSET FEATURES
And press ENTER



Scroll down to FSB & MEMORY CONFIG and press ENTER



Now change the above marked settings all to AUTO (Settings can be changed back later)
(use PageUP and PageDown keys to change the Values)

Press F10 to SAVE and EXIT